Coolpad QuattroIITM 4G (801ES) User Guide

Table of Contents

YOUR PHONE	1
FUNCTIONS OF KEYS	2
1. GETTING YOU STARTED	3
Charge the battery	3
Power phone on & off	
Touch screen & typing directions	4
Other touch tips	4
2. MORE BASICS	
How your phone looks	6
Screen-lock security options	6
Modifvina phone sounds	7


Changing other settings	7
Screenshots	
3. PHONE APPS MADE SIMPLE	9
Make a call	9
Answer & redirect calls	9
Explore the call log	10
Check your voicemail	
4. TEXTING & KEYBOARD USE	
Entering & editing text	12
Next-word suggestions	
5. CUSTOMIZING & USING YOUR 4G COOLPAD QUATTRO II PHONE APPS	
Customize your Home screen	14
Contact Book	

Setting up & using Gmail	15
Control your calendar	17
Operate the alarm	18
Managing your downloads	
6. PHONE SET-UP AND PHONE MANAGEMENT	20
Privacy settings & accounts	20
Manage location history	
Managing sound, screen & sleep settings	21
Notifications	
Airplane mode	22
7. WIRELESS NETWORK SETTINGS	23
Turning on Wi-Fi	23
Modify network settings	

Add on a Wi-Fi network	24
Set Wi-Fi advanced options	25
8. CONNECT TO BLUETOOTH	
Power Bluetooth on/off	26
Changing your phone's Bluetooth name	
"Pair" your phone with a Bluetooth device	27
Connecting to a Bluetooth device	
"Un-pair" or align a Bluetooth device	28
Monitoring your phone's data usage	
9. CREATING & SHARING VIDEOS, PICTURES	30
Creating a video	30
Taking a photo	
Sharina a video or photo	31

10. DATA USAGE SETTINGS	32	
Manage your data usage settings	3	32
Setting a data usage limit warning		
Setting your data usage limits		
11. GOOGLE PLAY STORE		
Accessing Play Store	3	34
Google Play Settings		
12. USB FILE TRANSFERS		
Windows transfer	3	36
Mac OS transfer		
13. OPTIMIZE YOUR PHONE'S BATTERY LIFE		
Battery settings		
14. COOLPAD OUATTRO II 4G SPECS & HARDWARE		

Your Phone



Functions of Keys

Keys	Functions	
Menu Key	Tap the option interface to enable the Menu pop-up.	
Home Key	Application interface returns to the Desktop.	
Back Key	Return to the previous interface.	
Volume Key	Adjust the volume of calls, ringtone, music and videos.	
Power/Screen Lock Key	Tap to turn off the background light. Tap to re-activate the phone. Press and hold to turn on or off the Power.	

Note: Touch Screen Menu, Home and Back are tap keys .

1. Getting you started

Get off to a running start with your new Coolpad Quattro 4G II

Charging the battery

- 1. First, connect one end of the data cable to the charger port. This is located at the bottom of your phone.
- 2. Connect the other end to the travel adapter.
- 3. Connect the travel adapter to an electrical outlet & fully charge your phone.




Use the travel adapter that accompanies your phone; using other adapters may damage your phone.

Charging your phone through a USB cable that is attached to a laptop takes more time than charging it with the travel adapter.

Power phone on & off

- The **Power key** is located on the upper, right-hand side of your phone. Press and hold the **Power key** for a few seconds to turn on your phone.
- To turn off your phone, press and hold the **Power key** to enable the Menu pop-up, and then select **Power Off**.



Touch screen & typing directions

- 1. Tap selected icon or other items in order to select or activate them.
- 2. For typing a message, select **Message icon** at bottom of your phone and the keypad will appear.

Coolpad Quattro™ II 4G

- 3. For Swype-typing, which can be an easier method of typing by swiping, select **Yes** at prompt asking whether you'd like to use Swype Technology.
- 4. Otherwise, type as normal for messaging, and also for Google searches.

Other touch tips

- ✓ Touch & continuously hold an object on your phone screen without lifting your finger, you can then reorganize your apps layout or drag apps to the home screen .
- ✓ To drag something, touch & hold an object without lifting your finger, then move your finger on the screen until you reach the object.
- ✓ Slide or swipe by quickly gliding your finger across the surface of the screen without pausing. Lift your finger before spelling a new word or name.
- ✓ To zoom in/enlarge, double-tap by tapping two times on a screen object (such as Google Maps). Tap again two times to zoom out.
- ✓ Some apps allow you to zoom in & out by placing two fingers on the screen, pinching them towards each other or spreading them apart to zoom in or out, respectively.

2. More basics

How your phone looks

- 1. Back Key: Return to your prior screen.
- 2. Home Key: Opens home.
- 3. Menu Key: Pull up setting menus.
- 4. Close or open recent apps: holding down the home key opens a list of your recent apps. Tap an app to open it or remove an app from the list by swiping left or right.

Screen-lock security options

- 1. To lock your phone, press the **Power key** (on the phone's right side) briefly, and let go.
- 2. To unlock, press **Power key** on, let go & slide the Padlock icon to the right.



Modifying phone sounds

Go to **Settings > Device > Sound** to modify your phone's notification sounds. **Adjust Volume** by pressing buttons on the side of your phone.

Changing other settings

To modify your phone's Brightness or Font size, go to Settings > Device > Display

To Customize wallpaper

Go to Settings > Device > Display > Wallpaper

Screenshots

- 1. To take a screenshot, focus on the image so it displays on your phone screen.
- 2. Press the **Power key & Volume Down keys** at the same time.
- 3. The image will be auto-saved in your phone's Gallery.

3. Phone apps made simple

Making a call



- Tap the Phone icon on your Home or All Apps screen to make a call.
- Calls can also be made from the Phone app or any other widgets or apps that contain your contact information, by simply tapping the phone number.
- Once you are in the Phone app, there are three tabs at the top. Tap any one of them for making calls.
- The **Call log icon** displays your recent calls. Tap a number to return the call.
- The **Contacts icon** displays frequently called numbers along with your contacts. Tap to dial.
- Touch the red **Phone icon** at the bottom of your phone to hang up.

Answering & redirecting calls

1. The Incoming Call screen pops up when a call is coming in, along with the caller ID & other

information you've entered in your Contact Book.

- 2. Any missed calls are logged in the Call log, along with a notification.
- 3. Press the **Volume Down key** on side of phone to mute the ringer.
- 4. There are various options for when a call comes in. To answer a call, slide the **Unlock key** over to the answering key on the right.

You may:

- ✓ Answer the call
- Start talking to the caller
- ✓ Send to voicemail
- ✓ Send a message by opening quick text responses & then tap one of them.

Note: To modify these standard text responses, tap **Menu > Settings > Quick responses**.

Exploring the call log

The Call log contains your history of calls received, missed or made.

- Tapping the number will reveal more information about the call.
- Tapping the phone icon beside the number returns the call.
- Tap to send a text message.
- Tap the **People icon** for contact info.
- Tap to + add New Contact.
- To clear your Call log, tap Menu > Clear Call History.

Checking your voicemail

Have a new voicemail? The Voicemail icon will pop up on your screen.

- Read your voicemail by swiping to reveal notifications.
- Voicemail notification shows number of unread messages & a number to dial.
- Check with your carrier to find out the default voicemail dial in number for your phone.

4. Texting & keyboard use

Entering & editing text

Enter text by using the screen's keyboard. To open your phone's keyboard, simply tap where you want to type.

- Otherwise, some apps will open the keyboard for you!
- To close the keyboard, tap the **Back key** below the keyboard.

Next-word suggestions

- 1. Tap where you want to type text.
- 2. Begin typing a word. Choose one of the words displayed above the keyboard.
- 3. If you don't want to use those words, type the next word without using the space bar.
- 4. Your phone will continue to present word choices while you type.



- 5. To turn Next-word suggestions on or off, go to Settings > Personal > Language & input > Keyboard & input methods > Android keyboard > Settings > Advanced settings.
- 6. Check the box adjacent to **Next-word suggestions**.





5. Customizing & using your Coolpad QuattroTM II 4G Phone Apps

Customizing your Home screen

- 1. Go to the Home screen where you want to position an app.
- 2. Tap the All Apps icon
- 3. Swipe right to locate your app (or widget), then touch it until the Home screen comes up.
- 4. After sliding the app into place, lift your finger.
 - To move an app (or widget icon) to a different place on a Home screen, touch & hold the icon, and then slide your finger to its new position.
 - ✓ To move between Home screens, swipe toward the edge of the screen. Move an icon out of the way by sliding slowly into it & lifting your finger. The icon will then fall into the new spot.

Contact Book

The Contact Book easily saves all of your important contact information including contact

- names, numbers and email addresses.
- It also supports an assortment of other communication operations.



- To search your Contacts, tap the **Search key** in Contact List, enter search characters in the search box & the Coolpad system will automatically reveal matching results.
- To add a New Contact, tap **Add Contact** on the Contact List & select the storage location of the New Contact.
- Type the contact information in **Edit Contact** & save **New Contact** in your Contact List.

Setting up & using Gmail

- 1. Tap the **Gmail icon** for reading and composing emails.
- 2. To open it, tap the **Gmail icon** on a Home or All Apps screen. Here Gmail has various uses. For instance, utilize your Gmail account for signing in to all Google apps & services, including, but not limited to:



- ✓ Calendar
- ✓ People, keeping track of Contacts

✓ Google Drive

Getting familiar with your Email App:


- 1. Tap the icons and menu along the top of the screen to archive, delete, label, or enable other message actions.
- 2. Swipe left or right to read prior or new email conversations.
- 3. Check the box next to a message in order to select it.
- 4. Tap the menu & icons at the top of your phone screen to manage your messages.
- 5. Enter your current email address, or add a new one, followed by your password.
- 6. Press & hold the email account for a pop-up menu to customize your Email Settings.
- 7. Upon turning on your phone & signing into a Google account, current contacts from that account are auto-synced with your People app.

Note: If you are using Microsoft Exchange, that contact info can also be

Controlling your calendar

To open your calendar, tap the **Calendar icon** on a Home or All Apps screen.

- If you have synced your Gmail account, the first time you open the Calendar app on your phone, it will show your current calendar events.
- To modify the Calendar view, choose Day, Week, Month or Agenda from the top of the screen by tapping on the month/year.
- Edit or view event details by tapping an Event.
- Tap desired icon(s) across the top of the screen, or Menu to search or generate new events, return to today, or adjust calendar settings.
- To invite people to a new event, tap the Calendar event from the Calendar app & tap Email guests.



When an event notification appears, swipe down on the notification shade, swipe to enlarge, & then tap Email guests.

Operating the alarm

For powering alarm On/Off, tap alarm & swipe to the left.

- > Tap **Time**, which will take you to Set Time.
- > Once your alarm is set, you may add a label to it & choose your
 Ringtone (or Vibrate) by selecting within the drop-down menu under Set Alarm.

Managing your downloads

- Tap the **Downloads icon** on the All Apps screen.
- To enjoy music, movies, etc., from Google PlayStore, Google servers stream your favorites from Google servers while you're playing them.
- Although they are not designed to occupy phone space, you can pin (aka download) books, movies, and other media in order to access everything offline.

- You can also download files from Gmail or other areas.
- Going to the Downloads app, tap an item to open it.
- Tap headings for earlier downloads to view them.
- Simply check what you'd like to share by tapping the **Share icon** & choosing a sharing method from the drop-down menu.
- Check any downloads that you want to delete, & then tap the **Trash icon**.
- Tap **Sort by size** or **Sort by date** at the bottom of your phone.
- If you are connecting your phone to a PC or laptop, view the Download directory for available files contained in the Downloads app. Here you may copy files as well.

6. Phone set-up and phone management

Privacy settings & accounts

These settings control your phone's Google Search privacy features & search-related confidentiality selections for your Google account.

Menu > Settings > Accounts > Search > Privacy & accounts.

From your phone's main Settings app:

Settings > Accounts > Google > Search.

Tap the Google Search setting to learn more.

Managing location history

- 1. Open Google Maps settings in order to turn on/off Location settings & Location reporting.
- 2. Google Location settings enable location access to be turned on/off.

Managing sound, screen & sleep settings

Sound settings: Go to **Settings > Device > Sound > Volumes.**

- Swipe the slider for volume levels on videos, Music, games, & other media.
- Or you can always press the volume control up/down on the left side of your phone.

Screen settings: Go to **Settings > Device > Display > Brightness.**

Sleep settings: Go to **Settings > Device > Display > Sleep**. Tap one of the options to select. Ringtone settings: Go to **Settings > Device > Sound > Phone ringtone** (or select Vibrate when ringing).

Notifications

- On the left of your phone, status icons will pop up displaying which apps have sent you notifications.
- For finding notifications, use two fingers to pull the notification shade down from the top of your phone screen, or swipe up, then to the right.
- The Quick Settings menu reveals your settings for Bluetooth, Wi-Fi, etc.
- To access Quick Settings, pull down the menu from the top, right side of your phone's screen with three fingers.

Airplane mode

Airplane mode is ideal for in-flight phone status, where no signal or Wi-Fi is connected.

Settings > Wireless & Networks > More...> Airplane Mode

7. Wireless network settings

Turning on Wi-Fi

At initial phone set-up, Wi-Fi is turned on automatically.

- 1. To turn Wi-Fi on/off, go to **Settings > Wireless & networks > Wi-Fi.**
- 2. To manage Wi-Fi data usage and mobile hotspots, go to **Settings > Wireless & networks > Data usage.**
- 3. Swipe the Wi-Fi switch to On for enabling your phone to scan for available Wi-Fi networks. It

Note: If you've been connected to a prior Wi-Fi network & your phone

will show the network(s).

4. Tap desired network name to connect, entering your password if necessary.

Modifying network settings

To modify a network's settings, press & hold a particular network name in order to change the network's settings.

Adding on a Wi-Fi network

- 1. A Wi-Fi network may be added so that your phone will recognize it along with any of its security credentials, and then it will auto-connect.
- 2. Always add a Wi-Fi network if the network name is not transmitted (SSID), or when you are out of range.
- 3. Tap the **Plus icon** on the top of your phone's screen.
- 4. Enter the SSID network name.
- 5. Tap **Save**. Your phone will auto-connect to this network whenever you return to its range.

Setting Wi-Fi advanced options

Go to Wi-Fi Settings screen, tap Menu



- You will receive Wi-Fi notifications for available networks in your status bar. To disregard notifications, uncheck this option.
- To save your phone's data usage, your phone will remain connected to Wi-Fi when your screen sleeps.
- To manage your phone's data usage and mobile hotspots, go to **Settings > Wireless & networks > Data usage.**

8. Connect to Bluetooth

Bluetooth has the capacity to connect several mobile devices at once, enabling superior synchronization while reversing challenges and problems that would otherwise occur. Use Bluetooth to maximize your 4G Quattro Coolpad II's awesome phone capabilities & functions!



Powering Bluetooth on/off

Tap **Settings > Wireless & networks > Bluetooth** and then slide the switch for Bluetooth to on (or off).

Changing your phone's Bluetooth name

Your phone contains a random Bluetooth name which will be visible to other Bluetooth devices during connection attempts. By changing the Bluetooth name, it will be more identifiable.

- 1. Go to **Settings > Wireless & networks**, and be certain Bluetooth is turned on.
- 2. Tap **Bluetooth**.

Coolpad Quattro™ II 4G

- 3. Within the Bluetooth screen, tap **Menu > Rename phone**.
- 4. Now enter a new name & tap **Rename**.

"Pairing" your phone with a Bluetooth device

When initially using a new Bluetooth device, it will be necessary to "pair" it with your phone, which is crucial in order to connect.

Now both devices save the connected record and will auto-connect for you next time.

If the device to pair with isn't contained on the list, confirm that it is turned on and that it is set to be detectable.

- 1. Go to **Settings > Wireless & networks** and ensure Bluetooth is turned on.
- 2. Tap Bluetooth. Your phone will begin seeking for nearby Bluetooth devices.
- 3. If your phone stops scanning before your Bluetooth device is ready, tap Search for devices.
- 4. Within the list, tap the ID of the Bluetooth device so as to pair with it. Follow the instructions to complete the pairing.
- 5. If necessary, enter a regular passcode such as 0000 or 1234. Likewise, consult the documentation that came with the device.

Connecting to a Bluetooth device

Now that your phone is paired with a Bluetooth device, it can be connected to it manually.

- 1. Go to **Settings > Wireless & networks > Bluetooth**, ensuring that Bluetooth is turned on.
- 2. Within the devices list, tap a paired and unconnected device.
- 3. The list will indicate that the device and the phone are connected.

"Un-pairing" or aligning a Bluetooth device

Some Bluetooth devices have multiple profiles. Profiles can include the ability to transmit your conversations, play music in stereo, or transfer files or other data.

You can select which profiles you want to use with your phone. You can also change the name of the Bluetooth device as it appears on your phone.

- 1. Under Settings > Wireless & networks > Bluetooth, ensure that Bluetooth is turned on.
- 2. Within Bluetooth settings, tap the **Settings icon** next to the connected Bluetooth device for which you are configuring.
- 3. You will now be offered the choices to either change the name, un-pair it or select profiles.
- 4. When you're done, tap the Back key.



Monitoring your phone's data usage

Although subject to your device and wireless plan, extra fees may be incurred when your data usage surpasses your plan's limit.

Therefore, it is imperative to monitor the data you've uploaded or downloaded on to your phone. Do this by going to **Settings > Wireless & networks > Data usage.**

9. Creating & sharing videos, pictures

Creating a video

- 1. To capture a video, simply tap the **Camera icon** from your Home screen.
- 2. Next, tap the Video Camera icon on the lower portion of your screen.
- 3. Now tap the red **record key** while using the screen in order to see your video while you're recording it.
- 4. Tap the **red key** once again to stop recording.

Taking a photo

- 1. To snap a picture, tap the **Camera icon**.
- 2. Tap the **Camera icon** once again on the lower part of your phone.
- 3. Focus on your subject by looking through your phone screen.
- 4. Press the **blue key** to take a picture.



Sharing a video or photo

- 1. To share a video or photo, first be sure to name it.
- 2. Then go to **Apps > Gallery.**
- 3. Tap your selected video & Share icon to the right of the video title/name.
- 4. From the drop-down options, select your method of sharing by tapping on it.
- 5. Tap **Gallery** to view and manage all of your videos and pictures.

It really is that easy! Your new Coolpad QuattroTM II 4G makes it that way.

10. Data usage settings

Manage your data usage settings

Here data usage settings for your new Coolpad Quattro[™] II 4G are described, but they are carrier-specific.

The following instructions will assist in tracing data usage, which may or may not help avoid possible

Note: Be sure to check with your carrier for further information. additional charges.

- 1. Go to Settings > Data usage > Slide Mobile data to On.
- 2. Here you will see a graph. The white lines that are vertically displayed present a time period within the data usage phase.
- 3. Touch and drag the white lines in order to change a data usage time period.

4. Your actual data usage is shown underneath the graph.

Setting a data usage limit warning

Touch and drag the **orange line** on its right side to the point where you wish to receive a data usage warning notification.

Setting your data usage limits

- 1. Go to Settings > Data usage > Slide Mobile data to On.
- 2. Activate the **red line** at the top of the graph by checking Set mobile data limit.
- 3. Touch and drag the **red line** on its right side to the point where you wish to set the limit. Your data will automatically switch off when your usage limit has been reached.
- 4. Various phone features will not work correctly and a notification will pop up at this time.

11. Google Play Store

Google Play Store is all-in-one entertainment point with music, movies, books and apps on the web.



Accessing Play Store

- 1. To access your Play Store app, tap the **Play Store icon** in your Favorites tray on your Home screen.
- 2. By tapping the **Menu** icon in any section, My Apps, My Music, etc., will pop up which will display your content for that part of Google Play.
- 3. Your Google Play content can be retrieved this way (from the Play Store app) even if you have acquired it through another phone.
- 4. Sign in to play.google.com to access your entertainment from any location.

Google Play Settings

- 1. Modify your Google Play settings by choosing the option you want from the Menu in the top right corner.
- 2. The Google Play settings screen enables you to:
 - ✓ Control game & app updates' notifications.
 - ✓ Clear search history.
 - ✓ Manage user controls.
 - ✓ Filter Android apps based on maturity level or that require a PIN in order to purchase.
 - ✓ Tap Content filtering.
 - ✓ Set or change PIN.

12. USB File Transfers

- By using a USB cable, you may transfer pictures, music, and other data files from your 4G Quattro Coolpad II on to your PC or laptop, & vice versa.
- For transferring files to Mac OS X, the Android File Transfer application can be utilized. (Refer to instructions below.)

Windows transfer

- 1. First, connect your phone to the computer's USB port. Its USB storage drive will show on the computer screen.
- 2. Begin copying files between your phone & the computer.
- 3. When you finish, eject the phone from within Windows before unplugging the USB cable.

Mac OS transfer

- 1. Install Android File Transfer http://www.android.com/filetransfer and follow the directions. Double-click for first-time use. (Auto-connect will occur thereafter.)
- 2. Connect your phone to the computer using a USB cable.
- 3. The Android File Transfer will begin, including a window pop-up showing your phone contents & other pertinent information.
- 4. Here you can open & close folders, create new folders, & drag files.
- 5. Disconnect the USB cable upon completion.

13. Optimize your phone's Battery life

Battery settings

Prolong your phone battery life by turning off apps that aren't being used or aren't needed. Go to **Settings > Device > Battery.**

Here you may monitor how apps, other data and your phone system all consume battery power.

- Turn off **Wi-Fi, Bluetooth** or **GPS** with the **Settings app**.
- For the GPS setting, go to **Settings > Personal > Location services**.
- Turn off **Navigation** or **Maps** when not in use.
- Dim your phone's screen brightness: **Settings > Device > Display**.
- Consider turning off auto-sync for all apps. **Go to Settings > Accounts > Google**.

Note: If auto-sync is turned off, you must manually sync to check emails, and notifications

account-name.

- Assessing battery level and usage, Go to **Settings > Device > Battery**.
- Battery usage for each app is displayed near the bottom of your phone screen.
- Get more details by tapping an app. For some apps, you may modify power usage settings, or halt the app entirely.

Note: If you stop some apps or services completely, your phone may not operate correctly.

14. Coolpad Quattro II 4G specs & hardware

Specifications			
Dimensions	133 mm × 66.5 mm × 11 mm		
Style	Candy Bar	Candy Bar	
Antenna	Built-in		
SIM Card	Micro SIM		
Network Mode	CDMA (EVDO) + LTE		
Camera	Front camera: 300,000 pixels; Rear camera: 5 megapixels		
Earphone Jack	Standard American earphone jack		
Screen Parameters			
Type	Dimensions	Resolution	

QHD	4.5 inches	960x540
Accessories	Battery Type	Lithium Ion Polymer Rechargeable Battery
Battery	Rated Capacity	1800 mAh
Nominal Voltage		3.7 V

Prompt: The battery capacity changes with battery upgrade.